


To calibrator L-N loop testers it is necessary to make an adapter lead as shown below :

UK Plug / Socket



EUROPEAN Plug / Socket

